

TI-NAP61G2


TRUVIEW AP

Quick Cloud Setup Guide

Basic CLOUD Setting

Register Your Cloud Account

1. Go to www.truviewcloud.net via a web browser.




2. Register your account with an email address.
3. Check your email to confirm your email address.


Basic CLOUD Setting

Binding Code (Unique Code)

1. Click Unique Code menu located at the top right portion after login Truviewcloud.net.



2. Click “Copy” button to copy your binding code.




* You can only use 1 cloud account per AP.

Local AP Setting

IP Scan Tool

1. Download Angry IP Scanning from Truviewcctv.com and Install it to find local IP of your AP. (Select Truview -> Truview_AP_IPtool)
2. Click Start to Scan your local network.
3. Host name start with TDAP000xxxxxxxx.
4. Access your AP via web-browser based on local IP that you've found via IP scanning tool.




Local AP Setting

Pairing AP with Cloud

1. Once you login to your AP via a web browser, click “Cloud” menu at the top right portion to change the mode for a cloud platform.



2. Click “Confirm” to change the mode.




Continued ⟶

Local AP Setting

Pairing AP with Cloud


3. Once the mode has been changed to “Cloud” mode, a cloud menu will appear on the main menu list.
4. Enter your binding code from your cloud account and click “Save/Apply”.



Verifying Pairing

Cloud Platform

1. Log into your cloud account, and select AP List.
   You will see the AP afterwards.



Questions? Call 201.646.0019 ext 2

